



Take a look inside and you will see what powers the Centrifugal Mass.<sup>™</sup> The wide body portion of the core makes the ball start transitioning at the first sign of friction. Once this happens, the weight block shifts into a whole new gear driving this ball right through the pins.

